



1-Bay SATA NAS Server

NAS-7101

User's Manual

Copyright (C) 2008 PLANET Technology Corp. All rights reserved.

The products and programs described in this User's Manual are licensed products of PLANET

Technology, This User's Manual contains proprietary information protected by copyright, and this User's Manual and all accompanying hardware, software, and documentation are copyrighted.

No part of this User's Manual may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form by any means by electronic or mechanical. Including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, and without the prior express written permission of PLANET Technology.

Disclaimer

PLANET Technology does not warrant that the hardware will work properly in all environments and applications, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose.

PLANET has made every effort to ensure that this User's Manual is accurate; PLANET disclaims liability for any inaccuracies or omissions that may have occurred.

Information in this User's Manual is subject to change without notice and does not represent a commitment on the part of PLANET. PLANET assumes no responsibility for any inaccuracies that may be contained in this User's Manual. PLANET makes no commitment to update or keep current the information in this User's Manual, and reserves the right to make improvements to this User's Manual and/or to the products described in this User's Manual, at any time without notice.

If you find information in this manual that is incorrect, misleading, or incomplete, we would appreciate your comments and suggestions.

CE mark Warning

There are class A and class B device, In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Trademarks

The PLANET logo is a trademark of PLANET Technology. This documentation may refer to numerous hardware and software products by their trade names. In most, if not all cases, these designations are claimed as trademarks or registered trademarks by their respective companies.

WEEE Regulation



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Revision

User's Manual for PLANET 1-Bay SATA NAS Server

Model: NAS-7101

Rev: 1.0 (April. 2008)

Table of Contents

1.	Introduction.....	1
1.1	Key Features	1
1.2	Package Contents	1
2.	Parts Name and Functions	2
2.1	Assemble of the Hard Disk Drive.....	3
2.2	Connection and Removing Connection.....	4
2.2.1	Network Connection	4
2.2.2	USB Printer & Storage Device Connection	4
2.3	Removing Connection	5
2.3.1	Removing USB Mass Storage Devices.....	5
2.3.2	Removing USB Printer	5
2.3.3	Removing Power connection.....	5
3.	Setup Wizard	6
4.	Web-based Management	9
4.1	Login	9
4.2	Quick Setup	10
4.2.1	Wizard.....	10
4.2.2	Add User	13
4.2.3	Add Group.....	14
4.2.4	Add Share	16
4.3	Users and Groups.....	17
4.3.1	User Management	17
4.3.2	Group Management.....	18
4.4	File and Print.....	18
4.4.1	File Server	18
4.4.2	Share Management	19
4.4.3	Printer Server	20
4.5	System.....	21
4.5.1	LAN Settings.....	21
4.5.2	Time Settings.....	22
4.5.3	Turn Off Server	22
4.5.4	Information.....	23
4.5.5	Disk Usage	23
4.5.6	Error Notification.....	24
4.6	Network Service	25

4.6.1 DHCP Server	25
4.6.2 Bonjour Setting	25
4.6.3 TorrentFlux.....	26
4.7 Maintenance	28
4.7.1 Disk Utility	28
4.7.2 Firmware Upgrade.....	28
4.7.3 Save Configuration	29
4.7.4 Restore Configuration.....	29
4.7.5 Factory Reset	30
4.7.6 Software Update.....	30
4.8 Personal Information	31
4.8.1 Account.....	31
4.8.2 Logout.....	31
5. Mapping a Network Drive in Windows XP	32
6. Printer Setup in Windows XP	34
7. Mounting SMB Server in Mac OS X	37
8. Mounting SMB Server in Linux.....	40
9. Network Applications	42
9.1 Personal Data Backup.....	42
9.2 Network File Sharing	42
9.3 FTP Server	43
9.4 Printer Server.....	43
9.5 USB Mass Storage Device	44
EC Declaration of Conformity	49

1.Introduction

Thank you for purchasing NAS-7101. It is a flexible, economical and powerful solution for your network storage application. The following instructions will help you to learn more about the connections, set-ups, and configurations of it.

1.1 Key Features

- The Administrator can Limit the Amount of Available Disk Space Available to Individual Users
- Aluminum Enclosure with an Internal Cooling Fan for Continuous Operation
- 2 Standard USB 2.0 Port for External USB HDD and Print Server Sharing
- Supports Windows Utility and Web Base Manage Internet
- Share Music, Pictures, Movies and Data over Network
- Supports BT Download
- Interface: 10/100/1000 Base-TX(Auto MDI/MDI-X), supports auto crossover detection
- Supports most popular OS including Windows VISTA/XP/2000, Mac OS x v10.2.1 or above, Linux.

1.2 Package Contents

NAS-7101 x 1

Power Adapter x 1


RJ-45 Cable x 1

CD Disk x 1

Quick Installation Guide x 1

- NOTE:**
1. If any of the above items are missing, please contact your dealer immediately.
 2. Using the power supply that is not the one included in NAS-7101 packet will cause damage and void the warranty for this product.

2.Parts Name and Functions




1 Power LED:	Power and access (blue) / Booting-up or reset(orange)
2 Front cover:	Covers the opening of the housing
3 Power button:	Push to turn on or off NAS-7101
4 Ethernet port:	Connects to the Ethernet cable with RJ-45 connector
5 USB host ports:	Connects to USB printers and USB Storage Devices
6 Reset key:	Press 10 sec to restore factory default
7 Security Slot:	Connects to a lock pin
8 DC In jack:	Connects to the AC adapter
9 Activity LED (yellow):	Activity status of Ethernet
10 Link LED (green):	Link status of Ethernet
11 Plastic Upper Frame:	Covers the groove and screws on the top of NAS-7101

LED Definition

LED Name	Operating Status	LED Color
Power LED	Booting up	Orange
	Power ON	Blue
	NAS Accessing	Blinking in blue
	Resetting	Orange
Link LED	Linked to the Ethernet	Green
	Disconnected from the Ethernet	No signal
Activity LED	Accessing the Ethernet	Orange
	Not Accessing	No signal


2.1 Assemble of the Hard Disk Drive



1. Extract the plastic upper frame by sliding it out the gape on the top of the case.
2. Unfasten the screw on the lower part of the front cover. Remove the front cover by lifting the clip with a flat screw driver.
3. Place the device horizontally; align the hard disk drive with the PCB board. Push slowly and gently to the most inside until the hard disk drive is firmly seated.
4. Assemble the enclosure by fastening the screws on both top and bottom sides.
5. Attach the front cover to the case and secure the screw on the lower part.
6. Restore the plastic upper frame by sliding it into the gape on the top of the case. Make sure the plastic upper frame matches the direction.


2.2 Connection and Removing Connection

2.2.1 Network Connection



- ❶: Connect NAS-7101 and a Switch, Hub, Router, or a computer with a RJ-45 Ethernet cable.
- ❷: Connect the power supply to NAS-7101.
- ❸: Press the “Power button” to turn on NAS-7101. The orange LED on the front cover will light up during booting-up. This device will be ready to use when the blue LED lights up steadily.

2.2.2 USB Printer & Storage Device Connection



- ❶: Connect NAS-7101 and a Switch, Hub, Router, or computer with a RJ-45 Ethernet cable.
- ❷: Connect USB printer(s) or USB storage device(s) to this device with USB cable(s). NAS-7101 can automatically mount the USB devices connected.
- ❸: Connect the power supply to NAS-7101.
- ❹: Press the “Power button” to turn on NAS-7101. The orange LED on the front cover will light up during booting-up. NAS-7101 will be ready to use when the blue LED lights up steadily.

2.3 Removing Connection

2.3.1 Removing USB Mass Storage Devices

NAS-7101 will auto-mount a USB Storage Device connected to it. But you need to manually unmount the USB Storage Device before disconnecting it. You can unmount a USB drive by **Control Panel > Maintenance > Disk Utility > clicking “Umount” button.**

2.3.2 Removing USB Printer

You have to unmount the printer before disconnecting it. You can unmount a USB printer by **Control Panel > File and Print > Printer Server > Unchecking “Enable” box.**

2.3.3 Removing Power connection

Press the “Power button” to turn off NAS-7101, and then remove its connections.

3.Setup Wizard

NOTE: This Setup Wizard is offered by the chipset vendor - STORLINK to make easy to set up NAS-7101.


Insert the bundled CD into the CD-ROM drive to launch the autorun program. Once completed, a welcome menu screen will appear.

Click the "Setup Wizard" hyperlink; you will see the Setup Wizard dialog box as below. Click "Setup" to continue.

NOTE: If the welcome screen does not appear, click "Start" at the taskbar. Then, select "Run" and type "D:\Utility\setup.exe", assume D is your CD-ROM drive.




Press "Search again" button. Setup Wizard will list all network storage in your LAN environment. Please check next section. Please select your network storage and press "OK". User can setup IP address, day and time step by step.




Please enter password. Default password is: admin. Then click "OK".



You can select "Set IP configuration manually" and enter the IP settings. Or select "Automatically obtain an IP address (DHCP)" when there is a DHCP server in your network.




You may change the time zone, date and time to your network storage and press "Next" to continue.



This page shows the new configurations. If it is correct, please press "Save" button and the setting information will be save to your network storage.



You are about to change the settings. Press "OK" to save new settings. Press "Cancel" if you want to keep current settings.



Click "Exit" button to close Setup Wizard.



4. Web-based Management

4.1 Login

Start the web browser on the computer and type the IP address of the NAS-7101. The Default IP: “ <http://192.168.0.100> “



The login window of NAS-7101 will appear, Default login username/password is : **admin / admin**



Username

Password

4.2 Quick Setup

4.2.1 Wizard

To setup basic configurations of NAS-7101, follow the diagram below.

1. Language Setting. Specify the language of this GUI.



PLANET Networking & Communication

1-Bay SATA NAS

Basic Control Panel Personal Info Logout

Quick Setup

Wizard

- > Add User
- > Add Group
- > Add Share

Step 1/6

Preference Language Setting - admin

Language Preference

Back Next Cancel

2. Password Setting. Click "Next" to skip password change.



PLANET Networking & Communication

1-Bay SATA NAS

Basic Control Panel Personal Info Logout

Quick Setup

Wizard

- > Add User
- > Add Group
- > Add Share

Step 2/6

New Password Setting - admin

New Password

(Please type your password again)

NOTE: If you do not wish to change the password, click **Next** button to advance to the next step.

Back Next Cancel

3. Hostname Setting. This hostname can be seen in My Neighborhood.

The screenshot shows the Planet 1-Bay SATA NAS configuration interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. A left sidebar contains 'Quick Setup', 'Wizard', 'Add User', 'Add Group', and 'Add Share'. The main content area is titled 'Step 3/6 Hostname Setting' and features a text input field for 'Hostname' with the value 'nas-7101'. Below the input field is a note: 'NOTE: The **Hostname** is the name given to the server by which Window based machine may access.' At the bottom right, there are three buttons: 'Back', 'Next', and 'Cancel'.

4. Internet Protocol Setting. You may specify a stationary IP address/DNS server address or enable the “Obtain IP address/DNS server address automatically” checkbox, depending on your LAN configuration.

The screenshot shows the Planet 1-Bay SATA NAS configuration interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. A left sidebar contains 'Quick Setup', 'Wizard', 'Add User', 'Add Group', and 'Add Share'. The main content area is titled 'Step 4/6 Internet Protocol Setting'. It has two sections: 'IP Address' and 'DNS Server'. In the 'IP Address' section, the 'Obtain IP Address automatically' radio button is selected. Below it are input fields for IP Address (192, 168, 0, 100), Subnet Mask (255, 255, 255, 0), and Default Gateway. In the 'DNS Server' section, the 'Obtain DNS Server Address automatically' radio button is selected. Below it are input fields for Primary, Secondary, and Others DNS server addresses. At the bottom right, there are three buttons: 'Back', 'Next', and 'Cancel'.

5. Time Setting. Adjust date, time, and time zone of your local position. Or select a NTP(Network Time Protocol) server for automatic time setting and calibration.

PLANET 1-Bay SATA NAS

Basic Control Panel Personal Info Logout

Quick Setup Wizard Add User Add Group Add Share

Step 5/6

Time Settings

Date Month 1 Day 1 Year 2007

Time Hour 12 Minute 8 PM

Time Zone (GMT+08:00) Taipei

NTP Server Default User Define

None

Back Next Cancel

6. Wizard Setting Confirmation. Click complete to implement above settings.

PLANET 1-Bay SATA NAS

Basic Control Panel Personal Info Logout

Quick Setup Wizard Add User Add Group Add Share

Step 6/6

Wizard Setting Confirmation

	Current Settings	New Settings
UI Language	browser	browser
Hostname	nas-7101	nas-7101
IP Address	Automatic Obtain	Automatic Obtain
	IP Address	IP Address
	Subnet Mask	Subnet Mask
	Default Gateway	Default Gateway
DNS Server	Automatic Obtain	Automatic Obtain
	Primary	Primary
	Secondary	Secondary
	Others	Others
Date and Time	1/ 1/2007 0: 8 PM	1/ 1/2007 0: 8 PM

Back Confirm Cancel

4.2.2 Add User

To add user support, select the Add User chapter for setting. Please refer to Users and Groups chapter for more detail.

1. Add User. Setup user name and password. Check "Crate Private Folder" box for creating a home directly of this user.

PLANET Networking & Communication **1-Bay SATA NAS**

Basic Control Panel Personal Info Logout

Quick Setup

- > Wizard
- > Add User
- > Add Group
- > Add Share

Step 1/3

Add User

User Name

Password

Please type your password again

Description (optional)

Create Shared private Folder

Shared Private Folder Location

Enable Quota of MB

Back Next

2. User Management. Add/remove this user to/from an existing group.

PLANET Networking & Communication **1-Bay SATA NAS**

Basic Control Panel Personal Info Logout

Quick Setup

- > Wizard
- > Add User
- > Add Group
- > Add Share

Step 2/3

User Management - enm

Member Non-member

==== END LIST =====

guest-share


==== END LIST =====

<< Add

Remove >>

Back Next

- Share Permission. Set user permission of each shared directory. Select a share name from the "Access Denied" column and click "Read Only" or "Writable" to allow user access right. Select a share name from the "Access Granted" column and click "Remove" to disable user access right from this directory.



4.2.3 Add Group

To add group support, select the Add Group chapter for setting. Please refer to Users and Groups chapter for more detail.

- Add Group. Set up group name.



- Group Members. Set up group members. Select a user from the “Non- Members” column and click “**Add**” to categorize it into this group. Select a user from the “Members” column and click “**Remove**” to remove this user from this group.

- Share Permission. Set group permission of each shared directory. Select a share name from the “Access Denied” column and click “**Read Only**” or “**Writable**” to allow group access right. Select a share name from the “Access Granted” column and click “**Remove**” to disable group access right from this directory.

4.2.4 Add Share


To add a sharing directory, select the Add Share chapter for setting. Please refer to Share Management chapter for more detail.

1. Add Share. Set up the directory name.



The screenshot shows the PLANET 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. A left sidebar menu shows 'Quick Setup' with sub-items: 'Wizard', 'Add User', 'Add Group', and 'Add Share'. The main content area is titled 'Step 1/3 Add Share'. It contains three input fields: 'Share Name' (with 'ShareFolder' entered), 'Path', and 'Description (Optional)'. At the bottom right, there are 'Back' and 'Next' buttons.

2. Windows, FTP access. Set user/group permission of this directory in Microsoft Network and FTP environment. Select a share name from the "Access Denied" column and click "Read Only" or "Writable" to allow user/group access right. Select a share name from the "Access Granted" column and click "Remove" to disable user/group access right from this directory. Check the box "Grant access to all" will enable writable permission of this directory to all users/groups.



The screenshot shows the PLANET 1-Bay SATA NAS web interface at 'Step 2/3 Windows, FTP Access - sharefolder'. It features a checkbox for 'Grant access to all'. Below this are two columns: 'Access Granted' and 'Access Denied'. The 'Access Granted' column contains a text box with '==== END LIST ====='. The 'Access Denied' column contains a list of users/groups: 'admin', 'enm', 'guest-share', '@guest-share', and '@planet'. Between these columns are three buttons: '<< Read Only', '<< Writable', and 'Remove >>'. At the bottom right, there are 'Back' and 'Next' buttons.

The prefix "@" denotes Group Name.

- NFS Access. Set IP access permissions of this shared directory in Unix-like environment. Input IP Address and click "Add" to add this IP to the allowed list. Input Subnet (the start of allowed IP address before the slash; the end of allowed IP address after the slash) and click Add to add this subnet section to the allowed list. Check "Allow to All" box to enable NFS access of this directory to all users.

The screenshot shows the Planet 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar has 'Quick Setup' with sub-items: 'Wizard', 'Add User', 'Add Group', and 'Add Share'. The main content area is titled 'Step 3/3 NFS Access - sharefolder'. It features a checkbox for 'Grant access to all', a text area for 'Allowable IP/Subnet' containing '==== END LIST =====', and an 'Add' button. To the right, there are radio buttons for 'IP Address' (selected) and 'Subnet', followed by input fields for IP addresses and subnets. At the bottom right, there are 'Back' and 'Confirm' buttons.

4.3 Users and Groups

4.3.1 User Management

All existing users in this system will be shown in this menu. You can create a new user by filling out the form and clicking the "Save" button. Select an existing user and click "Delete User" button to delete an existing user. Select an existing user and click "Groups" button to enter Group Management menu. Check "Create Private Folder" box for creating a home directory of this user.

The screenshot shows the Planet 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar has 'Users and Groups' with sub-items: 'User Management', 'Group Management', 'File and Print', 'System', 'Network Service', 'Maintenance', and 'Log File'. The main content area is titled 'User Management'. It features a text area for 'Existing Users' containing 'admin', 'enm', 'guest-share', and '==== END LIST ====='. Below this are input fields for 'User Name', 'Password', and a second password field with the prompt 'Please type your password again'. There is also an optional 'Description' field. Two checkboxes are present: 'Create Shared private Folder' (checked) with a 'Shared Private Folder Location' field containing '/mnt/ide4', and 'Enable Quota of' followed by an empty field and 'MB'. At the bottom, there are 'Save', 'Clear Form', 'Groups', and 'Delete User' buttons.

4.3.2 Group Management

All existing groups in this system will be shown in this menu. You can create a new group by filling out the form and clicking the “**Save**” button. Select an existing group and click “**Delete Group**” button to delete an existing group. You can also add or remove users from an existing group by selecting a group name and clicking the “**Members**” button.

The screenshot shows the Planet 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar menu is expanded to 'Users and Groups', with 'Group Management' selected. The main content area is titled 'Group Management' and features a text box labeled 'Existing Groups' containing the text: 'guest-share', 'planet', and '***** END LIST *****'. Below this is a 'Group Name' input field and four buttons: 'Save', 'Clear Form', 'Members', and 'Delete Group'.

4.4 File and Print

4.4.1 File Server

The screenshot shows the Planet 1-Bay SATA NAS web interface with the 'File and Print' section selected in the sidebar. The main content area is titled 'File Server Setting' and contains several configuration sections: 'File Server Setting' with a 'Character set' dropdown menu set to 'Traditional Chinese (CP950)'; 'Windows Setting' with 'Enable' checked, 'Workgroup' set to 'WORKGROUP', 'Description' set to 'NAS-7101', and 'WINS Server (Optional)' with four empty input boxes; 'FTP Server Setting' with 'Enable' checked, 'Enable FTP with TLS' unchecked, and 'Port Number' set to '21'; 'NFS Server Setting' with 'Enable' checked; and 'Guest Access Setting' with 'Enable' checked, 'Enable Quota' unchecked, and 'Guest-user Quota' set to an empty input box followed by 'MB'. A 'Save' button is located at the bottom right of the settings area.

Character Set Select your preferred character set.

Windows Setting Check “**Enable**” box to enable Microsoft Network connection

Set Workgroup name for Microsoft Clients to access. You can find this Workgroup name in My Network Places.

Set Description name for Microsoft Clients to access. You can find this Description name in **My Network Places/Entire Network/Microsoft Windows Network/Workgroup**

name”/.


Define Windows Internet Server Name IP address if necessary.

FTP Server Setting Check “**Enable**” box to enable FTP server function, with default port 21.

NFS Server Setting Check “**Enable**” box to enable NFS server function.

Guest Access Setting Check “**Enable**” box to allow users using guest-share directory.

4.4.2 Share Management



Creating Share Fill out the “**Share Name**” box, and then click the “**Save**” button to create a new share name.

Property Change You can modify properties of an existing share name. Select a share name in the “**Existing Share**” column and click “**Windows, FTP Access**” or “**NFS Access**” button to set or remove read/write permissions of the selected directory.

Delete Share Check “**Delete Share**” to delete a specified share name.



Windows and FTP Access Select a share name from the “**Access Denied**” column and click “**Read Only**” or “**Writable**” to allow user/group access right. Select a share name from the “**Access Granted**” column and click “**Remove**” to disable user/group access right from this directory. Check the box “**Grant access to all**” will enable writable permission of this directory to all users/groups.




NFS Access Set IP access permissions of this shared directory in Unix-like environment. Input IP Address and click **“Add”** to add this IP to the allowed list. Input Subnet (the start of allowed IP address before the slash; the end of allowed IP address after the slash) and click **Add** to add this subnet section to the allowed list. Check **“Grant access to all”** box to enable NFS access of this directory to all users.

4.4.3 Printer Server



Check **“Enable”** box to enable Printer Server function.


Uncheck **“Enable”** box to unmount a mounted printer.



This device detects the connection of a USB printer automatically. Information of the printer will be shown in the description.

4.5 System

4.5.1 LAN Settings



Hostname Assign a name to NAS-7101 as the identification within your local area network.

IP Address Setting	Obtain IP Address Automatically	NAS-7101 obtains an IP address automatically if a DHCP server is present in the local area network.
	Use Following IP Address	Fill in the IP address, subnet mask, and Default gateway information if they are assigned by your network administrator.
	Obtain DNS Server Address Automatically	NAS-7101 obtains a DNS Server address automatically if a DHCP server is present in the local area network.
	Use Following DNS Server Address	Fill in the DNS server addresses if they are assigned by your network administrator.

4.5.2 Time Settings

Set current Date, Time, and Time zone.

Specify a NTP Server if you want to get date and time from Time Server.

The screenshot shows the PLANET 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar menu is expanded to show 'Time Settings'. The main content area is titled 'Time Settings' and contains the following fields:

- Date: Month 1, Day 1, Year 2007
- Time: Hour 12, Minute 22, PM
- Time Zone: (GMT+08:00) Taipei
- NTP Server: Default (None), User Define (empty text box)

Buttons for 'Save' and 'Update Time' are located at the bottom of the form.

Date & Time Click this option to set time and date manually

Time Zone Set the time difference from Greenwich Mean Time in the area where the device is installed.

NTP Server Select default or type the host name or IP address or domain name of the NTP server in User Define box.

4.5.3 Turn Off Server

The screenshot shows the PLANET 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar menu is expanded to show 'Turn Off Server'. The main content area is titled 'Turn Off Server' and contains the following text and buttons:

To restart the server, click the Restart button.
To turn off the server, click the Turn off button.

Buttons for 'Restart' and 'Turn off' are located at the bottom of the page.

To restart NAS-7101, click the “**Restart**” button.

To power off NAS-7101, click the “**Shutdown**” button.

4.5.4 Information

The screenshot shows the PLANET 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar contains a tree view with categories: Users and Groups, File and Print, System (expanded), LAN Settings, Time Settings, Turn Off Server, Information, Disk Usage, Error Notification, Network Service, Maintenance, and Log File. The main content area is titled 'System Information' and displays the following details:

Product Name	NAS-7101
Firmware Version	2.6.3-n.20080320
Product Vendor	PLANET Technology Corporation
IP Address	192.168.0.100

Display system information.

4.5.5 Disk Usage

The screenshot shows the PLANET 1-Bay SATA NAS web interface with the 'Disk Usage' section selected. The left sidebar is the same as in the previous screenshot. The main content area is titled 'Disk Usage' and shows 'Last Checked: 1/1/2007 12:24:00'. Below this is a table with a dropdown menu set to 'Summary' and a 'Refresh' button.

Disk Name	Capacity	Used	Free	Disk Usage (%)
/dev/hdd	299851MB	128MB	299722MB	0%

Display HDD usage (total disk size, used disk size) and user's quota information.

4.5.6 Error Notification

PLANET 1-Bay SATA NAS

Basic | **Control Panel** | Personal Info | Logout

- Users and Groups
- File and Print
- System
 - LAN Settings
 - Time Settings
 - Turn Off Server
 - Information
 - Disk Usage
 - Error Notification**
- Network Service
- Maintenance
- Log File

Error Notification Setting

Monitoring Services Setting

Disk Usage

Windows File Sharing Server

FTP Server

DHCP Server

Check Interval

Interval:

Email Notification Setting

Enable

Error Handling Mail Server

Error Handling Email Addresses

Pop-Up Notification Setting

Enable

Error Handling Pop-Up Machine Name

Monitoring Service Setting	Disk Usage	If the disk usage reaches 90%, the system will inform the administrator.
	Windows File Sharing Server	If the SAMBA task goes wrong, the system will inform the administrator.
	FTP Server	If the FTP Server task goes wrong, the system will inform the administrator.
	DHCP Server	If the DHCP Server task goes wrong, the system will inform the administrator.

Check Interval You can select hourly or daily inform interval.

Email Notification Setting	Enable	Check this box to enable notification via email.
	Error Handling Mail Server	Specify a SMTP server for this device.
	Error Handling Email Address	Specify administrator email address.


Pop-up Notification Setting **Enable** Check this box to enable notification via Windows pop-up messages.

Error Handling Pop-up Machines Specify the IP address of administrator's PC.

4.6 Network Service

4.6.1 DHCP Server

If there is no DHCP server present, this device will automatically turn on its DHCP server function.



The screenshot shows the Planet 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar menu lists 'Users and Groups', 'File and Print', 'System', 'Network Service', 'DHCP Server', 'Bonjour', 'Maintenance', and 'Log File'. The main content area is titled 'DHCP Server Setting' and contains the following options:

- Enable Server
- DHCP Client Setting
 - Subnet Mask (optional)
 - Default Gateway (optional)
 - Primary DNS (optional)
 - Secondary DNS (optional)
 - Others DNS (optional)
 - DHCP IP Address Start
 - DHCP IP Address End
 - Maximum Lease Time

At the bottom of the settings area are three buttons: 'Save', 'DHCP lease list', and 'Static IP'.

4.6.2 Bonjour Setting

If enabled, then the user can listen music that stored in the NAS via iTunes client.



The screenshot shows the Planet 1-Bay SATA NAS web interface. The top navigation bar includes 'Basic', 'Control Panel', 'Personal Info', and 'Logout'. The left sidebar menu lists 'Users and Groups', 'File and Print', 'System', 'Network Service', 'DHCP Server', 'Bonjour', 'Maintenance', and 'Log File'. The main content area is titled 'Bonjour Setting' and contains the following options:

- Enable
- iTunes Enable


At the bottom of the settings area is a 'Save' button.

4.6.3 TorrentFlux

TorrentFlux is an open source bit torrent client. Check “**Enabled**” box to perform TorrentFlux. Click “**Save**” button to save check box status. Click “**Link to bt**” button to open TorrentFlux in another browser window. Visit <http://www.torrentflux.com/> for more information of this program.



The login window of TorrentFlux will appear, Default login username/password is : **mysql / 123456**





Select a Torrent for upload Specify the torrent file with which you need download files. You can upload it from local PC.

URL for the Torrent File Specify the torrent file with which you need download files. You can upload it from provide one HTTP/FTP URL for it.

Torrent Search

1. Enter the keywords you wish to search for in the text field labeled Torrent Search.
2. Select the torrent search engine you wish to use from the dropdown list next to the text box.
3. Click the Search button.

Torrent Details View the detailed information of the task.

Run Torrent Start to run the selected task.

Stop Torrent Stop the selected task.

Seed Torrent Download finish

Delete Delete selected tasks.

4.7 Maintenance

4.7.1 Disk Utility

Disk Utility shows device name, type of file system, volume mounted, and disk mount status of the HDD installed in this device. For a newly attached HDD, formatting is required before any further operation.

Device Name	Type	Mount Point	Status	Encrypt	Password/Format Type/Format	Scandisk	Umount	Health
/dev/hdd	ext3	/mnt/ide4	mounted	<input type="checkbox"/> encrypt	ext3 Format	Scan	Umount	PASSED Detail

Refresh

Disk spin down time: Minute [Save](#)

Format Button

Press this button to format a specific HDD. It supports EXT3, and FAT32 file system. Check the encrypt box to allow password protection over the HDD.

Scan Button

Press this button to check disk integrity.

Umount button

This device will automatically mount a USB Storage Device connected to it. But you need to manually unmount the USB Storage Device before disconnecting it.

Detail Button

If the HDD supports S.M.A.R.T, it will report its health status.

Disk Spin Down Time

Specify the HDD spin down time if there is no access to this device for some while.

4.7.2 Firmware Upgrade

You can perform firmware upgrade with this function by selecting a firmware upgrade file and then clicking the “**Start Upgrade**” button. When the upgrade is in progress, all network connection will be stopped. This device will automatically reboot after the upgrade is completed.

Planet 1-Bay SATA NAS

Basic Control Panel Personal Info Logout

Firmware Upgrade


Current Firmware Version 2.6.3-n.20080320

Upgrade File [Browse...](#)

[Upgrade](#)

4.7.3 Save Configuration

This device can save its current configuration to a local file. The default file name is “config.tar”.



4.7.4 Restore Configuration

You can restore system configuration from a previously saved config file saved by “Save Configuration” function. Specify a config file and then click the “Restore” button to restore previous settings.




4.7.5 Factory Reset

“Factory Reset” resets all configurations to factory defaults. All users, networking, and other configurations will be lost once the “**Factory Reset**” button is pressed.



4.7.6 Software Update


Select an installation module and click “**Upload**” button to install it on this device.



4.8 Personal Information

4.8.1 Account

Account is the only section in “Personal Information”. You could change the password of user ‘admin’ and the language of the GUI. Besides, share list, system disk quota and the percentage of disk used will be shown as well.



4.8.2 Logout

Click Logout to logout off this device.


5. Mapping a Network Drive in Windows XP

After mapping a specific folder as a Network Drive, you can access it easily in **My Computer**.


We will show you an example of this operation in Windows XP. For other operation systems, please refer to the manuals of their respective manufacturers.

A USB external drive connected to this device will be seen as `\\your-hostname\usb1` or `\\your-hostname\usb2` in Windows Explorer. You can also map it with the following steps.

1. Click **Start** button in Windows taskbar => Click **Search** => Click **Computer or people** => Click **A computer on the network** and a new window will appear.
2. Input the hostname of this device in the Computer Name column, which you set previously in Control Panel > System > LAN Settings > Hostname chapter; or you can also input the description of this device, which you set previously in Control Panel > File and Print > File Server > Windows Setting > Description. Click the Search button, and you will find search results in the right column.



3. Double click on the computer icon. You can also access this device directly by inputting "`\\your-hostname`" in the URL bar of an Explorer window.
4. Right click on the folder you want to map and select **Map Network Drive**.




5. A Map Network Drive dialogue box will be shown. Specify a drive letter for the folder chosen and click **Finish** button to complete mapping.



6. A "Connect to Your-Hostname" dialogue box will be shown. Input a username and its password your previously set in **Control Panel > File and Print > Windows and FTP Access**. You can enable automatic login process in the future by checking the "remember my password" box. You will need to input the username and its password again each time you tried to access this network drive if the "remember my password" box is left unchecked.



7. The selected folder will now be shown in **My Computer**. You can then access it like a local hard drive.



6. Printer Setup in Windows XP


You can enable access of a network printer to members in the same LAN environment. We will show you an example of this operation in Windows XP. For other operation systems, please refer to their manuals of respective manufacturers.

Take the installation of EPSON AcuLaser C1100 printer as an example.


1. Connect the USB printer to NAS7101 with the printer's USB cable directly. The printer will be automatically detected by NAS-7101.




2. Input "\\your-hostname" (default arinas) in the URL bar of an Explorer window. Double click on the "lp" icon.



3. A dialogue box will pop up. Click Yes to continue.




4. Another dialogue box will pop up. Click OK to continue.




5. In the Add Printer Wizard window, select the manufacturer and printer model corresponding to the printer connected. If the manufacturer of the specific model of your printer is not available in the list, click on the “Have Disk...” button to install its driver from the driver disk provided by the manufacturer.




6. Insert the driver disk into your local computer. Click the “Browse...” button to select the corresponding INF file in the driver disk. Click OK to proceed on installation.



7. Click OK to proceed on installation.



8. A “Connecting to lp on your-hostname” dialogue box will pop up during the installation process. The installation process may take several minutes to complete, please wait.




9. When the installation process is complete, a “lp on your-hostname” window will be shown. Now you can print documents using the printer installed. Each member in the LAN will have to complete above installation before using this printer.




7. Mounting SMB Server in Mac OS X

First, you have to make sure that local Mac and NAS-7101 are in the same LAN environment. Then you can connect to NAS-7101 using SMB protocol, by inputting a URL starts with “**smb://**”.


1. Click on the **Apple Menu**, and select **Location -> Network Preferences**.




2. A Network window will show. Select **Built-in Ethernet** in the **Show:** pop-up menu.



3. Select **Using DHCP** in the **Configure IPv4** pop-up menu.



4. The private IP address acquired from the DHCP server is now displayed in this window. You can find the IP Addresses of this Mac and of this device are within the same LAN environment.



5. Select **Go -> Connect to Server** in the menu bar.



6. The “Connect To Server” window will be shown. Input **smb://NAS-IP**, and then click **Connect**.




7. A “Connecting to smb://NAS-IP” progress bar will be shown first, followed by the “SMB Mount” window. Select a folder (ex: **admin**) in the “Select a share” pop-up menu and then click OK.



8. Input Username and Password in the “SMB/CIFS Filesystem Authentication” window, and then click **OK**.



9. If the connection succeeded, you can see the NAS icon in the left column.



10. Click the symbol by the right side of the NAS icon to unmount this device.



8. Mounting SMB Server in Linux

The following operation is performed in Fedora command line environment. The IP address of this device is set to 192.168.0.100 (its default value). Actual scenario of application may vary from case to case.

1. Using the **smbclient** command to check the content of the NAS-7101.
2. Input **smbclient -L 192.168.0.100 -U admin** after the prompt. The system will prompt you with “**Password:**”. Input **admin** (the default password for user **admin**) to get a list of directories within the NAS-7101.

```
[root@localhost misc]# smbclient -L 192.168.0.100
Password:
session setup failed: NT_STATUS_LOGON_FAILURE
[root@localhost misc]# smbclient -L 192.168.0.100
Password:
Domain=[PLANET] OS=[Unix] Server=[Samba 3.0.20]

  Sharename      Type      Comment
  -----
  admin           Disk
  public          Disk      Folder Share for public
  guest-share    Disk      Folder Share for guest
  usb1            Disk      usb disk
  IPC$            IPC       IPC Service
  ADMIN$          IPC       IPC Service
  Ip              Printer   Generic dot-matrix printer entry
Domain=[PLANET] OS=[Unix] Server=[Samba 3.0.20]

  Server          Comment
  -----
  Workgroup        Master
  WORKGROUP        ARINAS
[root@localhost misc]#
```

3. Create a folder as the mount point for the NAS-7101.

Input **mkdir /mnt/admin** after the prompt for mounting of the shared directory “admin”.

```
[root@localhost ~]# mkdir /mnt/admin
```

Input **mkdir /mnt/usb1** after the prompt for mounting of the USB external drive.

```
[root@localhost ~]# mkdir /mnt/usb1
```

4. Mount the NAS-7101 with **mount** command.

Fedora 5 and later: Input **mount -t cifs -o username=admin //192.168.0.100/admin /mnt/admin/** after the prompt to mount the shared directory.

```
[root@localhost ~]# mount -t cifs -o username=admin //192.168.0.100/admin /mnt/admin/
Password:
[root@localhost ~]#
```

Input **mount -t cifs -o username=admin //192.168.0.100/ /mnt/usb1/** after the prompt to mount the USB external drive.

```
[root@localhost ~]# mount -t cifs -o username=admin //192.168.0.100/usb1 /mnt/usb1/  
Password:  
[root@localhost ~]# █
```

Fedora 4 and earlier: Input **mount -t smbfs -o username=admin //192.168.0.100/ /mnt/admin/** after the prompt.

After the input of the **mount** command, the system will prompt you with "**Password:**". Input the corresponding password of the user.

5. Unmount a directory mounted.

Input **umount /mnt/admin/** to unmount the shared directory.

```
[root@localhost ~]# umount /mnt/admin/  
[root@localhost ~]# █
```

Input **umount /mnt/usb1/** to unmount the USB external drive.


```
[root@localhost ~]# umount /mnt/usb1/  
[root@localhost ~]# █
```

9. Network Applications

9.1 Personal Data Backup

For a single user, you can use NAS-7101 as an external hard drive to store your data via Ethernet connection.


Personal Backup



9.2 Network File Sharing

With NAS-7101, a group of people in a LAN environment can share and store files over Ethernet connection. NAS-7101 could work with 10/100/1000 Base-T Ethernet environment.


Files Sharing / Remote Data Backup



9.3 FTP Server

NAS-7101 features FTP function. You can access the FTP via a web browser or a FTP client.


1. If you are in the same LAN of NAS-7101, simply input **"ftp://your-account @your-hostname_or_IP address/"** in your browser's URL bar and press Enter key; or open a connection by **your-hostname** (or its **IP address**) with a FTP client. Login with a set of username and password you set previously to get access to NAS-7101.
2. If you are accessing NAS-7101 over Internet connection, the router of NAS-7101 will have to set a NAT mapping on port 21 for FTP protocol. In the URL bar of your browser, input **"ftp://your-account@router-hostname_or_router-public-IP"** instead. It is recommended to have a static IP address for the router of the FTP server to enable stable connections.



9.4 Printer Server

Connect a USB printer to NAS-7101 and share this printer to members in the same LAN.


Note: GDI Interface printers are not supported.



9.5 USB Mass Storage Device

Connect your USB Mass Storage Device to NAS-7101. The two USB ports can supply up to 350mA of current in total. If you would like to connect a USB external HDD to one of the USB host ports, it is recommended to apply external power to the USB HDD.

NAS-7101 will automatically mount a USB Mass Storage Device connected to it. A USB external drive connected to NAS-7101 will be seen as `\\your-hostname\usb1` or `\\your-hostname\usb2` in Windows Explorer. But you need to manually unmount the USB Mass Storage Device before disconnecting it. You can unmount a USB drive by **Control Panel > Maintenance > Disk Utility > clicking "Umount" button**.



EC Declaration of Conformity

For the following equipment:

*Type of Product : 1-Bay SATA NAS Server
*Model Number : NAS-7101

* Produced by:

Manufacturer's Name : **Planet Technology Corp.**
Manufacturer's Address : 11F, No. 96, Min Chuan Road, Hsin Tien
Taipei, Taiwan, R.O.C.

is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (89/336/EEC, 92/31/EEC, 93/68/EEC).

For the evaluation regarding the Electromagnetic Compatibility, the following standards were applied:

EN 55022	(2006, Class B)
EN 61000-3-2	(2000 + A1: 2001)
EN 61000-3-3	(1995 + A1: 2001)
EN 55024	(1998+A1: 2001+A2: 2003)
IEC 61000-4-2	(1995 + A2: 2000)
IEC 61000-4-3	(2002)
IEC 61000-4-4	(1995 + A2: 2001)
IEC 61000-4-5	(1995 + A1: 2000)
IEC 61000-4-6	(1996 + A1: 2000)
IEC 61000-4-8	(1993 + A1: 2000)
IEC 61000-4-11	(2004 + A1: 2000)

Responsible for marking this declaration if the:

Manufacturer **Authorized representative established within the EU**

Authorized representative established within the EU (if applicable):

Company Name: Planet Technology Corp.

Company Address: 11F, No.96, Min Chuan Road, Hsin Tien, Taipei, Taiwan, R.O.C

Person responsible for making this declaration

Name, Surname John Sung

Position / Title : Product Manager

Taiwan
Place

2nd Apr., 2008
Date

John
Legal Signature

PLANET TECHNOLOGY CORPORATION